

ASSEMBLY INSTRUCTIONS

MIRROR ADAPTERS KIT YAMAHA R6 '18

YP6-18-ADATT

KIT

X2. SPECIFIC PLATE
X4. TEFLON WASHER

WWW.BARRACUDAMOTO.COM

ASSEMBLY PROCEDURE:

1. DISASSEMBLE THE ORIGINAL MIRRORS AND UNTHREAD THE ELECTRIC CABLES LIFTING THE FRONT FAIRING.
2. MOUNT THE SPECIFIC PLATES USING THE BOLTS (SUPPLIED WITH THE MIRROR KIT) AND THE TEFLON WASHERS, AS FROM THE PICTURE.
3. TIGHTEN EVERYTHING.

